

When storing the Tube Series Conveyors for long periods of time, the following procedure must be followed to reduce the chance of rust, corrosion and fatigue of the conveyor. You can also use these steps when storing the machine for the winter.



A dust mask and protective rubber gloves shall be used when cleaning the machine.

- 1. Clear the area of bystanders, especially small children.
- 2. Thoroughly wash the entire machine to remove all dirt, mud, debris or residue.
- 3. Inspect all moving or rotating parts to see if anything has become entangled in them. Remove the entangled material.
- 4. Lubricate all grease fittings. Make sure that all grease cavities have been filled with grease to remove any water residue from the washing. This also protects the bearing seals.
- 5. Remove drive assembly cover. Clean entire area and ensure drive belt is clean and free of debris.
- 6. Touch up all paint nicks and scratches to prevent rusting.
- 7. Select an area that is dry, level and free of debris.
- 8. If possible, store the machine inside a protective building to keep it from being exposed to the weather. If storing outside, cover the entire machine with a large waterproof tarpaulin. If you do not have one large enough, at a minimum cover all electric motors.
- 9. Unhook from towing vehicle.
- 10. Place blocks under the intake or the jack if required.
- 11. Store machine in an area away from human activity.
- 12. Do not allow children to play on or around the stored machine.